

Plastic related design

Missing or too small radii result in high stress-concentrations

